

# FINE CRACK FILLER & FINE CRACK FILLER COLD CURE

Non shrink, two part liquid epoxy crack fillers for concrete floors



### AREAS OF USE

- Narrow cracks in concrete floors
- Small holes less than 50mm diameter and 25mm deep

### FEATURES

- Can be coated with any of our high performance floor coatings
- Super tough, epoxy resin formula
- Fast curing – non shrink
- Ideal for cracks up to 3mm wide

### DESCRIPTION

Watco Fine Crack Filler is a simple to use, incredibly tough product for filling unsightly cracks in concrete floors prior to coating. Its liquid formulation ensures that no sanding down will be needed to make it level once cured. The cold cure version can be applied at temperatures as low as 0°C.

### SPECIFICATION

Composition	100% solids epoxy resin formula.	Pot Life	20 - 30 minutes.
Number of Components	1 x resin, 1 x curing agent.	Shelf Life	12 months in unopened containers.
Usage Interior/ Exterior	Exterior & Interior.	Storage	Store at a temperature range of approximately 15°C - 25°C for at least 8 hours prior to use.
Application Tools	Straight edge or plastic/rubber scraper.	Safety	Material Safety Data Sheets are available. Food products must be removed from the area during application and cure.
Suitable For	Concrete.	Principle Limitations	Watco Fine Crack Filler and Watco Fine Crack Filler Cold Cure will not remedy structural or bonding problems and are intended for surface filling only. Cracks caused by structural movement may reappear if movement persists.
Pack Size	500ml	Please contact us regarding applications not described here.	
Coverage	500ml will fill over 25 linear metres of a crack 2mm wide and 5mm deep (please note that nearly all cracks will vary in dimension along their length so coverage figures cannot be precise).		
Curing Time	Fine Crack Filler: Normally 3 - 4 hours at 20°C. Curing time will be extended by low temperatures. Fine Crack Filler Cold Cure: Normally 4 hours at 0°C - 5°C.		

### PREPARATION & APPLICATION

#### SURFACE PREPARATION

Clean and rake out cracks ensuring that they are dry and free from dust etc. It is not normally necessary to 'chase out' cracks.

#### MIXING

Each Watco Fine Crack Filler/Fine Crack Filler Cold Cure pack contains a tin of curing agent and a separate tin of resin. Add the contents of the curing agent tin to the tin of resin and stir thoroughly with a flat mixing blade. Scrape down the sides and bottom of the tin during mixing to avoid unblended resin/curing agent creating 'soft spots' in the cured product.

#### APPLICATION

Pour carefully out of the tin onto and along the line of the crack and level off by using a straight edge or plastic/rubber scraper. Wipe away any excess. Leave to harden for 4 hours at 20°C for Watco Fine Crack Filler or 4 hours at 0°C-5°C for Watco Fine Crack Filler Cold Cure.

The repair may be coated with any type of floor paint or high performance coating eg: Watco Epoxy Gloss Coat.

**PLEASE NOTE** – Cracks in floors where one side has subsided can also be filled, but it will be impossible under these circumstances to achieve a flush finish. Watco Concrex may be used to make up differences in floor levels.



[WATCO.CO.UK](http://WATCO.CO.UK)